ELECTRICAL TOOLS



PH-60C SWIV PUNCH* KNOCKOUT **PUNCH HEAD**



BENEFITS

- · Effortlessly punch up to 4" holes without burdensome ratcheting or pumping
- Compatible with knockout punch dies from RIDGID and other manufacturers
- · Head can be rotated to virtually any orientation to access tight spaces
- · Combine with other heads in the RIDGID QuickChange System to maximize efficiency and productivity on the job site

The Swiv-L-Punch Head, compatible with the exclusive RIDGID® QuickChange System™, delivers unparalleled efficiency to contractors and electricians.

SPECIFICATIONS

- Capacity: Punches up to 4" holes in 12 gauge mild steel and 14 gauge stainless steel
- Interchangeable head is compatible with 6-ton RIDGID Electrical Tools featuring the RIDGID QuickChange System
- Punch head swivels 360° and rotates 360° in the RIDGID QuickChange System
- Approximate Punch Time: 5 seconds
- Weight: 4.6 lbs. (2.1 kg)
- · Available as stand-alone head or in a RE 6 Tool Kit

ACCESSORIES

52278 Swiv-L-Punch Head Accessory Kit • Includes 2 spacers, 2 draw bolts, and 1 thread adapter 52378 Step Drill Bit

52278 & 52378 come standard with RE 6 Kit #52093. #52113, #52118 and #52123











Featuring the RIDGID QuickChange System



RIDGID.COM

ORDERING INFORMATION

,,,		_	 -	-
	TS	*		

CATALOG NO.	DESCRIPTION	NO. OF HEADS	CUT SC-60C	CRIMP 4P-6	PUNCH PH-60C
52093	RE 6 Cut, Crimp, & Punch Kit**	3	✓	✓	✓
52098 52113 52118	RE 6 Cut & Crimp Kit** RE 6 Cut & Punch Kit** RE 6 Crimp & Punch Kit	2	- ^	✓ - ✓	- √ √
52103 52108 52133 52123	RE 6 Crimp Only Kit RE 6 Cut Only Kit (Cu/Al Blades) RE 6 Cut Only Kit (ACSR Blades) RE 6 Punch Only Kit	1	- > >	- - -	- - - -
52088	RE 6 Tool Only Kit (No Heads)	0	_	_	_

^{*}All Kits Include: RE 6 Electrical Tool, (2) 18V Advanced Lithium 2 batteries, battery charger and blow-molded case **Includes SC-60C Cutter Head with Copper/Aluminum Blades

ACCESSORIES

AUDEOUGHILO			
CATALOG NO.	DESCRIPTION	WEI (lb.)	GHT (kg)
46818	RE 6 Electrical Tool Only	5.5	2.5
52083	RE 6 Electrical Tool Case Only	11.3	5.1
52283	4P-6 4PIN™ Dieless Crimp Head Only	5.8	2.6
52078	Swiv-L-Punch Head Only	4.6	2.1
52278	Swiv-L-Punch Head Accessory Kit	1.2	0.5
52378	Step Drill Bit	0.1	0.1
47918	SC-60C Cutter Head – Copper/Aluminum Wire Blades	4.7	2.1
49408	SC-60C Cutter Head – ACSR Wire Blades	4.7	2.1
47923	Replacement Blades for Copper/Aluminum Wire	0.5	0.2
47928	Replacement Blades for ACSR Wire	0.5	0.2
44693	18V Advanced Lithium 2.0Ah Battery	1.0	0.5
44698	18V Advanced Lithium 4.0Ah Battery	1.5	0.7
43458	Advanced Lithium Battery Charger	1.8	8.0
44798	Advanced Lithium Battery Charger Replacement Cord	0.3	0.1

RE 6 Electrical Tool, Attachments & Accessories





SC-60C Scissor Cutter Head

Cat. No.	Description
47918	SC-60C Cutter Head With Copper/Aluminum Blades
49408	SC-60C Cutter Head With ACSR Blades
47923	Replacement Blades for Copper/Aluminum Wire
47928	Replacement Blades for ACSR



4P-6 4PIN™ Dieless Crimp Head


Cat. No.	Description
52283	4P-6 4PIN Dieless Crimp Head Only




Knockout Punch Sets

Cat. No.	Description
23487	KOPD-52 Set with 1/2", 3/4", 1", 11/4", 11/2", 2" Punches, Dies and Case
	KOPD-254 Set with 21/2", 3", 31/2", 4" Punches and Dies and Case

How the RIDGID® QuickChange System™ Works




1 Select the appropriate interchangeable head for the job.



2. Pull back the collar and insert the head until you hear a click confirming the connection.



3. Complete the job-cut, crimp or bunch.



4. Remove the head by pulling the movable collar toward the base of the tool.