

NOTE: Order parts by Catalog Number only. DO NOT order by Reference Number.

$\overline{}$		
Ref. No.	Catalog <u>No.</u>	<u>Description</u>
_	36738	micro CA-100
1	40968	LCD Cover Assembly
2	40973	LCD Assembly
3	40978	PCB Assembly
4	40983	Handle Set
5	40993	Battery Holder Assembly
Items Not Shown		
	45943	micro CA-100 Case