

**RIDGID  
R3250 TWIN BLADE SAW  
REPAIR SHEET**

**RIDGID  
R3250 SCIE À LAME DOUBLE  
FEUILLE DE RÉPARATION**

**RIDGID  
R3250 SIERRA CON DOBLE HOJA  
LISTAS DE PIEZAS DE REPUESTO**





# R3250

KEY	P/N	DESCRIPTION	QTY	KEY	P/N	DESCRIPTION	QTY	KEY	P/N	DESCRIPTION	QTY
1	039438001108	Upper Guard Assembly.....	1	20	039438001038	Compression Spring.....	1	39	039438001070	End Cap.....	1
2	039438001004	Lock Nut (3/4 in.).....	1	21	039438001039	Spindle Lock Button.....	1	40	039438001071	Hex Nut (M5).....	1
3	039438001079	Blade Wrench.....	1	22	039438001040	Gear Case Cover.....	1	41	039438001073	Screw (M4.2 x 9.5 mm, Pan Hd.).....	1
4	039438001006	Screw (M5 x 8 mm, Torx, Flat Hd.).....	2	23	039438001041	Screw (M4 x 20 mm, Torx Pan Hd.).....	4	42	039438001074	Screw (M4.2 x 16 mm, Pan Hd.).....	2
5	039438001007	Guide.....	1	24	039438001103	Auxiliary Handle.....	1	43	039438001075	Sleeve.....	1
6	039438001008	Torsion Spring.....	1	25	039438001045	Screw (M5 x 45 mm, Pan Hd.).....	1	44	039438001076	Guard Handle.....	1
7	039438001009	Lower Guard.....	1	26	039438001046	Spring Washer (M5).....	4	45	039438001077	Spring.....	1
8	039438001010	Spacer.....	1	27	039438001047	Washer (M5).....	4	46	039438001078	Screw (M4 x 15 mm, Torx Pan Hd.).....	3
9	039438001011	Screw (M5 x 20 mm, Torx, Shoulder).....	1	28	039438001049	Screw (M3.8 x 16 mm, Torx Pan Hd.).....	12	47	039438001106	Blade Assembly.....	1
10	039438001012	Bumper.....	1	29	039438001050	Screw (M3.8 x 40 mm, Torx Pan Hd.).....	2	48	039438001107	Handle Assembly.....	1
11	039438001013	Screw (M4 x 30 mm, Torx, Pan Hd.).....	4	30	039438001051	Switch.....	1	49	039438001201	Motor Assembly.....	1
12	039438001014	Spring Washer (M4).....	5	31	039438001052	Cord Clamp.....	1	50	039438001022	Screw (M5 x 5 mm, Special).....	3
13	039438001015	Washer (M4).....	5	32	039438001053	Bend Relief.....	1	<b>Not Shown:</b>			
14	039438001016	Dowel Pin.....	1	33	039438001054	Data Label.....	1	039438001080	Wax Stick.....	6	
15	039438001095	Cord Tag.....		34	039438001055	Power Cord.....	1	039438001081	Tool Bag.....	1	
16	039438001101	Knob Assembly.....	1	35	039438001063	Baffle.....	1	988000317	Operator's Manual (039438001093).....	1	
17	039438001109	Gear Case Assembly (Inc. Key No. 50)....	1	36	039438001064	Screw (M4.2 x 70 mm, Pan Hd.).....	2	9-4-13 (Rev:04)			
18	039438001035	Screw (M5 x 15 mm, Torx, Pan Hd.).....	3	37	039438001066	Motor Housing.....	1				
19	039438001037	Screw (M4.2 x 32 mm, Torx, Pan Hd.).....	4	38	039438001105	Brush Assembly.....	2				

CLÉ RÉF.	DESCRIPTION	QTÉ	CLÉ RÉF.	DESCRIPTION	QTÉ	CLÉ RÉF.	DESCRIPTION	QTÉ
1	039438001108	Ensemble de supérieure de garde ..... 1	19	039438001037	Vis (M4.2 x 32 mm, tête bombée Torx)..... 4	38	039438001105	Ensemble de charbon ..... 2
2	039438001004	Écrou de blocage (3/4 po) ..... 1	20	039438001038	Ressort de compression ..... 1	39	039438001070	Capuchon d'extrémité..... 1
3	039438001079	Clé de lame ..... 1	21	039438001039	Bouton de blocage de la broche..... 1	40	039438001071	Écrou hexagonal (M5)..... 1
4	039438001006	Vis (M5 x 8 mm, tête plate Torx)..... 2	22	039438001040	Couvercle du carter d'engrenages..... 1	41	039438001073	Vis (M4.2 x 9.5 mm, tête bombée) ..... 1
5	039438001007	Guide..... 1	23	039438001041	Vis (M4 x 20 mm, tête bombée Torx)..... 4	42	039438001074	Vis (M4.2 x 16 mm, tête bombée) ..... 2
6	039438001008	Ressort de torsion..... 1	24	039438001103	Poignée auxiliaire ..... 1	43	039438001075	Manchon ..... 1
7	039438001009	Garde inférieur..... 1	25	039438001045	Vis (M5 x 45 mm, tête bombée) ..... 1	44	039438001076	Poignée de garde ..... 1
8	039438001010	Entretoise ..... 1	26	039438001046	Rondelle ressort (M5) ..... 4	45	039438001077	Ressort ..... 1
9	039438001011	Vis (M5 x 20 mm, Torx, épaulée) ..... 1	27	039438001047	Rondelle (M5) ..... 4	46	039438001078	Vis (M4 x 15 mm, tête bombée Torx)..... 3
10	039438001012	Butoir..... 1	28	039438001049	Vis (M3.8 x 16 mm, tête bombée Torx)... 12	47	039438001106	Ensemble lame ..... 1
11	039438001013	Vis (M4 x 30 mm, tête bombée Torx)..... 4	29	039438001050	Vis (M3.8 x 40 mm, tête bombée Torx)..... 2	48	039438001107	Ensemble de poignée..... 1
12	039438001014	Rondelle ressort (M4) ..... 5	30	039438001051	Interrupteur..... 1	49	039438001201	Ensemble de moteur ..... 1
13	039438001015	Rondelle (M4) ..... 5	31	039438001052	Bride de cordon..... 1	50	039438001022	Vis (M5 x 5 mm, spéciale) ..... 3
14	039438001016	Goujon..... 1	32	039438001053	Soulagement de torsion du cordon..... 1	<b>Pas illustré:</b>		
15	039438001095	L'étiquette du cordon ..... 1	33	039438001054	Étiquette de données ..... 1	039438001080	Bâton de cire..... 6	
16	039438001101	Ensemble de bouton ..... 1	34	039438001055	Cordon d'alimentation..... 1	039438001081	Sac à outils..... 1	
17	039438001109	Ensemble de carter et couvercle (incl. lég. réf. 50) ..... 1	35	039438001063	Défecteur ..... 1	988000317	Manuel d'utilisation (039438001093) ..... 1	
18	039438001035	Vis (M5 x 15 mm, tête bombée Torx)..... 3	36	039438001064	Vis (M4.2 x 70 mm, tête bombée) ..... 2			
			37	039438001066	Boîtier du moteur..... 1			




R3250

NÚM. REF.	N/P	DESCRIPCIÓN	CANT.	NÚM. REF.	N/P	DESCRIPCIÓN	CANT.	NÚM. REF.	N/P	DESCRIPCIÓN	CANT.
1	039438001108	Conjunto del superior de protector .....	1	20	039438001038	Resorte de compresión .....	1	39	039438001070	Tapa extremo .....	1
2	039438001004	Contratuercas (3/4 pulg.) .....	1	21	039438001039	Botón de bloqueo del husillo .....	1	40	039438001071	Tuerca hexagonal (M5) .....	1
3	039438001079	Llave de hoja .....	1	22	039438001040	Cubierta de la caja de engranajes .....	1	41	039438001073	Tornillo (M4.2 x 9.5 mm, cab. trunc.) .....	1
4	039438001006	Tornillo (M5 x 8 mm, Torx, cab. plana) .....	2	23	039438001041	Tornillo (M4 x 20 mm, cab. trunc. Torx) .....	4	42	039438001074	Tornillo (M4.2 x 16 mm, cab. trunc.) .....	2
5	039438001007	Guía .....	1	24	039438001103	Mango auxiliar .....	1	43	039438001075	Casquillo .....	1
6	039438001008	Resorte de torsión .....	1	25	039438001045	Tornillo (M5 x 45 mm, cab. trunc.) .....	1	44	039438001076	Manija del protector .....	1
7	039438001009	Protección inferior .....	1	26	039438001046	Arandela elástica (M5) .....	4	45	039438001077	Resorte .....	1
8	039438001010	Separador .....	1	27	039438001047	Arandela (M5) .....	4	46	039438001078	Tornillo (M4 x 15 mm, cab. trunc. Torx) .....	3
9	039438001011	Tornillo (M5 x 20 mm, Torx, cuello grueso) .....	1	28	039438001049	Tornillo (M3.8 x 16 mm, cab. trunc. Torx) .....	12	47	039438001106	Conjunto cuchillas .....	1
10	039438001012	Tope .....	1	29	039438001050	Tornillo (M3.8 x 40 mm, cab. trunc. Torx) .....	2	48	039438001107	Conjunto de mango .....	1
11	039438001013	Tornillo (M4 x 30 mm, Torx, cab. trunc.) .....	4	30	039438001051	Interruptor .....	1	49	039438001201	Conjunto del motor .....	1
12	039438001014	Arandela elástica (M4) .....	5	31	039438001052	Abrazadera del cable .....	1	50	039438001022	Tornillo (M5 x 5 mm, especial) .....	3
13	039438001015	Arandela (M4) .....	5	32	039438001053	Protector del cordón .....	1	<b>No se muestra:</b>			
14	039438001016	Clavija .....	1	33	039438001054	Etiqueta de datos .....	1	039438001080	Palillo de cera .....	6	
15	039438001095	Etiqueta del cordón .....	1	34	039438001055	Cordón de corriente .....	1	039438001081	Bolsa de herramientas .....	1	
16	039438001101	Conjunto de la perilla .....	1	35	039438001063	Deflector .....	1	988000317	Manual del operador (039438001093) .....	1	
17	039438001109	Conjunto de caja de engranajes (incl. núm. ref. 50) .....	1	36	039438001064	Tornillo (M4.2 x 70 mm, cab. trunc.) .....	2				
18	039438001035	Tornillo (M5 x 15 mm, Torx, cab. trunc.) .....	3	37	039438001066	Alojamiento del motor .....	1				
19	039438001037	Tornillo (M4.2 x 32 mm, Torx, cab. trunc.) .....	4	38	039438001105	Conjunto de la escobilla .....	2				

**RIDGID**

**R3250**



**WIRING DIAGRAM / SCHÉMA DE CÂBLAGE / DIAGRAMA DE CABLEADO**